

Installation Instructions for LJ-3024 (100 pack) 1/2" Tapered Plugs LJ-3025 (25 pack) 1" Tapered Plugs

1. Apply a small amount of wood glue around the edge of the plug.
2. Make sure the grain direction of the plug matches the grain of the newel post or handrail. Gently tap into place using a wood block and hammer, leaving slightly above flush.
3. Sand the plug flush.

