

# Instructions for Using LJ-3033 Dowel-Runner™

1. With the Dowel-Runner™ mounted in chuck or the Chuck-Buster™ (3031), start up the drill motor and hand start the dowel screw in the runner.
2. Now that the screw is secure in the Dowel-Runner™, drive the screw to the desired depth in baluster base.
3. Reverse drill to disengage the Dowel-Runner™.

