

# Installation Instructions for LJ-3076 Dowel-Fast™ Screws

1. Using the Dowel-Runner™ (3033), drive the screw to the desired depth in baluster base.
2. Insert baluster with installed Dowel-Fast™ Screw into the pre-drilled hole in the tread.

