

Instructions for Using LJ-3040 Scrapers

Place scraper profile against the handrail profile being used and adjust the angle until the entire edge contacts, then draw the scraper toward you. L.J. Smith strongly recommends that this scraper be used only while attached to the Scraper Handle (3043). Improper use may result in serious bodily injury or death. When scraper is cutting properly, a curly chip will form.

To sharpen the scraper, use the Scraper Sharpener (3041).

